

616 GSR Insert - Cheat Sheet

The 616 GSR2 has several new features and characteristics that require special attention during installation and set-up. This unit uses the new GreenSmart 2 system. Refer to the owner's manual for full details.

GreenSmart™ 2

This heater has been updated with the 2013 version of GreenSmart[™] 2 components from SIT. These components function in a near identical fashion to the previous 2012 components. The primary differences are:

- The accent light now has dimming capability built into the remote.
- The pilot may be switched from intermittent (IPI) to standing pilot from the remote.

Remote Control / Pilot Warnings



Installing batteries in the battery holder or connecting the appliance to power may automatically initiate the CPI pilot mode, resulting in a lit pilot flame. Do not place combustibles in the firebox.



KEEP BATTERIES AND COVER INSTALLED AT ALL TIMES

The remote control system requires the batteries and battery cover to remain in place at all times. Once the batteries or cover are removed, the system may re-start in standing pilot mode. If this occurs when the heater is in Remote Mode, you will not be able to turn the heater off manually from the battery box. If you need to replace dead batteries, make sure to **turn the appliance off** before removing the batteries.

NOTE: If the batteries go dead, the system will operate normally as long as household power (120v AC) is present.

If using LP (Propane)

A conversion kit is required if using propane with this heater (sku 94400999 - GSR Stepper Motor Kit).

Additional Items

- Shipping Brackets on Side of Insert May be Removed and Discarded
 These brackets, and screws, are used to protect the insert. See surround panel instructions for details.
- Glass Tool is Attached to the Insert, Inside the Right Convection Chamber

 This insert uses a glass tool to remove the glass frame. It is shipped inside the right convection chamber, attached with a screw. See the photos below for glass frame removal. See manual for details.









- This Insert Requires a ½" Hearth 12" Deep See installation manual for details.
- If Using Tall Vent (over 25') You Must Open the Diffuser Before Attaching Vent

The diffuser must be adjusted before attaching the vent (it is attached to the vent connector and is concealed once the vent is installed). See owner's manual for details.

- Shipping Brackets on Side of Insert May be Removed and Discarded
 - These brackets, and screws, are used to protect the insert. See surround panel instructions for details.
- Vent Kit "G" (sku 96200331) May Be Used With This Insert
 - The co-linear 3" and 4" vent kit works with this insert. See manual for details.
- Power Cord Exits Behind Surround Panel

The power cord ships attached to the side of the insert. It may be re-routed to the front (exits between face and surround panel) by disconnecting the strain relief and molex connector.

Page 1 of 2 17601749 Printed 11/28/12



616 GSR Insert - Cheat Sheet

HAVE YOUR ACCESSORIES ON HAND WHEN INSTALLING THIS INSERT

This insert requires the following accessories:

- Media Kit (logs/stones)
- Firebacks
- Surround Panels
- Face

These accessories <u>are required</u> to ensure correct and safe operation. Do not operate the appliance without the firebacks in place.

ORDER OF INSTALLATION

When setting up the insert, you will need to follow a specific order of installation to optimize installation time. Failure to have all of the accessories available at the time of installation will delay installation and may lead to unnecessary disassembly of components.

- 1. Run gas line to the fireplace
- 2. Remove the glass frame.
- Run vent through fireplace chimney. On larger fireplaces, the vent connector may be left in place.
 For smaller fireplaces, remove the vent connector. See "Vent Connector Removal and Installation" for details.



INSTALLATION WARNING: If using a tall vent (over 25') – you must open the diffuser before attaching the vent. See "Diffuser Adjustment" for details.



INSTALL THE LIGHT SHIELD (ALL FACES EXCEPT SHADOWBOX). The light shield (shipped with the face) prevents light from exiting the upper grill area. Install this prior to placing the insert.

- 4. Place insert into position and attach the gas line and vent.
- 5. Remove the burner.

NOTE: If using propane (LP), convert the appliance at this time.

- 6. Install the firebacks.
- 7. Replace the burner.
- 8. Install the media (logs, stones see instructions included with the media).
- 9. Install the surround panel (see instructions included with surround panel).
- 10. Replace the glass.
- 11. Install the face (see instructions included with the face).
- 12. Follow the instructions under "Finalizing the Installation."

Page 2 of 2 17601749 Printed 11/28/12